



CXone Mpower EXPERT

クラスタネットワークスイッチをセットアップおよび設定する方法

https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/How_to_setup_and_configure_the_Clu...

Updated: Wed, 22 Apr 2026 07:29:04 GMT

のとう

のとう

環境

- ONTAP 9

説明

この資料では、NetAppクラスタネットワークスイッチとして導入されたCisco Nexus 50x0スイッチの管理と監視のためのセットアップと設定のベストプラクティスについて説明します。クラスタネットワークは、クラスタで動作するように設定された複数のData ONTAP 8 Cluster-Mode ノード間の接続を提供します。購入したスイッチは、正確なクラスタサイズに応じてNexus 5010またはNexus 5020モデルになります。モデルによって特別に呼び出されない限り、情報はすべてのNexus 50x0バリエーションに関連します。

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information