



CXone Mpower EXPERT

外部キー管理ツールにノードからアクセスした場合は、どのような状況になりますか？

https://kb-cn-stage.netapp.com/on-prem/ontap/dm/Encryption/Encryption-KBs/What_are_the_circumsta...

Updated: Wed, 22 Apr 2026 08:24:21 GMT

環境

- ONTAP 9
- NetApp Volume Encryption (NVE)
- NetApp アグリゲート暗号化 (NAE)

回答

ノードがキー管理ツールにアクセスするのは、次の場合です。

- ブート中
- 新しいボリュームのキーを作成するか、既存のボリュームのキーを変更します。
- ボリュームを削除してキーを削除します。
- 次のいずれかのコマンドから要求された場合：

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

```
security key-manager query
```

```
security key-manager restore
```

```
security key-manager show -status
```

追加情報

[FAQ : NetAppボリューム暗号化とNetAppアグリゲート暗号化](#)