



---

## AFF A400/FAS8300/FAS4700 nvme.Battery alerts Resolution Guide (《电池警报解决指南》)

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/AFF\\_A400\\_FAS8300\\_nvmem.battery\\_...](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/AFF_A400_FAS8300_nvmem.battery_...)

Updated: Wed, 22 Apr 2026 04:06:25 GMT

### 适用场景

- AFF A400、AFF C400
- ASA A400、ASA C400
- FAS8300、FAS8700

### 问题描述

- 本文介绍有关AFF A400、FAS8300、ASA A400、ASA C400、AFF C400和FAS8700系统上的nvme.b瓶消息的信息
- 故障排除将按特定的nvme.b瓶消息进行细分。

---

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information