



---

## AFF C30 机箱温度过冷警报

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/AFF\\_C30\\_Chassis\\_Temperature\\_too\\_...](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/AFF_C30_Chassis_Temperature_too_...)

Updated: Wed, 22 Apr 2026 08:24:19 GMT

### 适用于

- ONTAP 9
- AFF C30

### 问题描述

机箱温度对于 IO 卡来说太冷了，但不久之后就会消失

```
[Node01: env_mgr: monitor.chassisTemperature.cool:alert]: Chassis temperature is too cool: IO2 10G X710 Temp is warning low (0 C).
```

```
[Node01: env_mgr: monitor.chassisTemperature.ok:notice]: Chassis temperature is ok.
```