



## 控制器上的琥珀色 LED

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/Amber\\_LED\\_on\\_controller](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/Amber_LED_on_controller)

Updated: Wed, 22 Apr 2026 04:08:33 GMT

### 适用于

FAS/AFF 系统

### 问题描述

- 琥珀色指示灯亮起，但未发现可见问题或警报：

```
Cluster::> System health alert show
This table is currently empty.
```

- 检查日志 `SP-LATEST-IPMI` 我们看到有一个旧故障，在检查日志后，已解决但未清除

```
=====
hsamcmd --fault-show-all
=====
tag  origin  fld                                fault reason                                count  time
----  -

```

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

```
-----  
1   bmc   /chassis-1/controller-a/nvbatt-1   Bat_Design_Cap: Current Sensor  
95 UNC           1   Mon Dec 30 09:33:40 2024
```

- 正在检查我们可以看到已报告的事件：

```
Cluster::> system controller service-event show -instance  
           Node: Node-01  
Service Event ID: 1  
           Location: NV Battery on Controller A  
Description: Bat_Design_Cap: Current Sensor 95 UNC  
Timestamp: Mon Dec 30 09:33:40 2024
```