



---

## 现有硬件配置当前妨碍了可维护性

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/An\\_existing\\_hardware\\_configuration\\_i...](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/An_existing_hardware_configuration_i...)

Updated: Wed, 22 Apr 2026 07:32:34 GMT

### 适用场景

NetApp硬件

### 问题描述

现有硬件配置当前妨碍了可维护性。