



磁盘在ONTAP 中不可见

https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/Disk_not_visible_in_ONTAP

Updated: Wed, 22 Apr 2026 07:28:54 GMT

适用场景

- ONTAP 9
- AFF/FAS 系统

问题描述

- 磁盘在 `sysconfig -a` 或 `disk show` 输出中不可见
- 重新安装驱动器不会修复问题描述
- 由于缺少驱动器、已触发备用磁盘不足警告
- `run local -command storage show shelf -a` 不会显示驱动器应位于的插槽的任何输出：

示例：

Partial Path	Link	Invalid	Running	Loss	Phy	CRC	Phy	
Disk	Port	Timeout	Rate	DWord	Disparity	Dword	Reset	Error

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

Change

Id	State	Value	(ms)	(Gb/s)	Count	Count	Count	Problem	Count
[SQR0]	OK	7	6.0	0	0	0	0	0	1
[SQR1]	OK	7	6.0	0	0	0	0	0	1
[SQR2]	OK	7	6.0	0	0	0	0	0	1
[SQR3]	OK	7	6.0	0	0	0	0	0	1
[CIR4]	OK	7	6.0	0	0	0	0	0	1
[CIR5]	OK	7	6.0	0	0	0	0	0	1
[CIR6]	OK	7	6.0	0	0	0	0	0	1
[CIR7]	OK	7	6.0	0	0	0	0	0	1
[0]	OK	7	6.0	0	0	0	0	0	4
[1]	OK	7	6.0	0	0	0	0	0	2
[2]	OK	7	6.0	0	0	0	0	0	2
[4]	OK	7	6.0	0	0	0	0	0	2
[5]	OK	7	6.0	0	0	0	0	0	2