



# CXone Mpower EXPERT

## 驱动器显示在损坏的容器中、但工作正常

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/Drive\\_shows\\_in\\_broken\\_container\\_ho...](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/Drive_shows_in_broken_container_ho...)

Updated: Wed, 22 Apr 2026 09:00:25 GMT

### 适用场景

AF-A800

### 问题描述

报告节点上已损坏的池中存在此驱动器 但是、Sysconfig -a显示驱动器处于正常状态

```
::> storage disk show -broken Original Owner: Node name Checksum
Compatibility: block Drawer Usable Physical Disk Outage Reason HA Shelf Bay
/Slot Chan Pool Type RPM Size Size -----
----- 1.0.40 prefailing 0n 0 40 -/-
B Pool0 SSD-NVM - - 6.99TB ::> system node run -node <node name> -command
sysconfig -a 40 : NETAPP X4013S172B7T6NTE NA56 7325.4GB 4160B/sect
(SXXXXXXXXX36)
```