



---

## EMS 报告"ses.status.restematureWarning : alert"

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/EMS\\_reports\\_ses\\_status\\_temperature...](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/EMS_reports_ses_status_temperature...)

Updated: Wed, 22 Apr 2026 07:28:56 GMT

### 适用场景

DS2246

### 问题描述

- EMS 报告"ses.status.restematureWarning : alert"

示例：

```
[node01: dsa_worker3: ses.status.temperatureWarning:alert]: DS2246 (S/N SHFFGXXXXXXXXXX) shelf 10 on channel 0a temperature warning for Temperature sensor 7: not installed or failed. Current temperature: 27 C (80 F). This module is on the rear of the shelf at the top left, on shelf module A.
```

- environment 在ASUP中检查：

```
Temperature Sensor installed element list: 1, 2, 3, 4, 5, 6, 7, 8; with error:
```

---

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

none

Shelf temperatures by element:

- [1] 22 C (71 F) (ambient) Normal temperature range
- [2] 25 C (77 F) Normal temperature range
- [3] 26 C (78 F) Normal temperature range
- [4] 49 C (120 F) Normal temperature range
- [5] 26 C (78 F) Normal temperature range
- [6] 49 C (120 F) Normal temperature range
- [7] Unavailable >>>>>>>>> IOM A
- [8] 28 C (82 F) Normal temperature range