



CXone Mpower EXPERT

如何识别IOM12与IOM12B之间的区别？

https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/How_do_I_identify_the_difference_bet...

Updated: Wed, 22 Apr 2026 10:27:26 GMT

适用场景

- ONTAP 9
- DS224C、DS212C、DS460C SAS3 存储架
- IOM12、IOM12B 架模块

问题解答

- 视觉识别：
 - 模块上的标签显示“IOM12”或“IOM12B”，
 - IOM12模块没有蓝色条纹。IOM12B 模块的面板上有一条蓝色条纹。
- 查看 `storage shelf show -module` 或(nokeshell) `environment status shelf` 命令行界面命令的输出：
 - IOM12报告以下Mfg.3x5部件号：111-02850
 - IOM12B报告以下Mfg.3x5部件号：111-04850或111-05055
- 查看 `system controller config show` 或(nokeshell) `sysconfig -a` 命令行界面命令的输出：

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

- 。 磁盘架信息将报告IOM型号(IOM12或IOM12B)

Shelf 10: DS224-12 Firmware rev. IOM12B A: 0120 IOM12B B: 0120

追加信息

- [storage shelf show](#)
- [system controller config show](#)命令
- [热插拔或更换IOM12/IOM12B模块-磁盘架与IOM12/IOM12B模块](#)
- [NetApp Hardware Universe](#)