



---

## 如何访问加载程序提示符解析指南

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/How\\_to\\_get\\_to\\_the\\_LOADER\\_prompt...](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/How_to_get_to_the_LOADER_prompt...)

Updated: Wed, 22 Apr 2026 08:49:09 GMT

### 适用场景

- ONTAP 9
- Data ONTAP 8 7-模式
- AFF 系统
- FAS 系统
- ASA 系统
- LOADER

### 问题描述

介绍如何访问加载程序提示符的文章集

---

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information