



CXone Mpower EXPERT

如何在Windows上设置iSCSI MPIO

https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/How_to_set_up_iSCSI_MPIO_on_Win...

Updated: Wed, 22 Apr 2026 04:07:54 GMT

适用场景

- ONTAP
- FlexPod
- Windows Server 2008 及更高版本

问题描述

- 操作步骤、用于在Windows 2008、Windows 2008 R2、Windows 2012和Windows 2019上设置iSCSI MPIO
- 在开始之前完成ONTAP MPIO配置、并考虑必要的[MPIO/DSM参数](#)
 - 假设两个目标门户的IP地址位于每个ONTAP节点的存储上、而主机使用iSCSI软件启动程序、并具有两个用于MPIO /负载组合/故障转移的NIC。

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information