



---

## 重新启动或升级时LUN连接丢失

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/Lun\\_connection\\_lost\\_on\\_reboot\\_or\\_up...](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/Lun_connection_lost_on_reboot_or_up...)

Updated: Wed, 22 Apr 2026 11:57:57 GMT

### 适用场景

- ONTAP
- SAN

### 问题描述

每次重新启动节点或升级ONTAP时、与LUN的连接都会断开。