



CXone Mpower EXPERT

节点未启动、主机电源已关闭

https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/Node_not_powering_ON_Host_Power...

Updated: Wed, 22 Apr 2026 08:25:15 GMT

适用场景

- ONTAP 9
- AFF系统
- FAS系统

问题描述

- 节点未启动
- 尝试通过BMC启动时失败

```
BMC> system power on
..
BMC> system power status
Host power is off
```

- 尝试通过SP启动时失败

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

```
SP > system console
Type Ctrl-D to exit.
```

```
Running Backup Firmware
SP > system power status
Host Power is off
Running Backup Firmware
SP > system power on
Running Backup Firmware
SP > system power status
Host Power is off
Running Backup Firmware
```

- 重新拔插节点、所有DIMM和PCI卡后问题描述仍然存在