



## ONTAP 驱动器 X357\_S16433T8ATE 出现故障，并显示 "故障 - 不支持" 状态

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/ONTAP\\_Disk\\_X357\\_S16433T8ATE\\_fa...](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/ONTAP_Disk_X357_S16433T8ATE_fa...)

Updated: Wed, 22 Apr 2026 10:27:28 GMT

### 适用场景

- ONTAP 9
- 磁盘 X357\_S16433T8ATE

### 问题描述

磁盘驱动器出现故障，Failed-Unsupported 状态为：

00.22: NETAPP X357\_S16433T8ATE NA53 0.0GB 0B/sect (Failed-Unsupported)