



SES.STATUS · 温度传感器警告

https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/ses.status.temperature_Sensor_Warning

Updated: Wed, 22 Apr 2026 07:28:53 GMT

适用场景

- ONTAP 9
- AFF A200

问题描述

- 磁盘架报告温度过高。
- EMS日志显示以下错误。

```
[node-01: dsa_worker2: ses.status.temperatureWarning:alert]: DS224-12 (S/N SHFFG18330XXX4) shelf 0 on channel 0b temperature warning for Temperature sensor 11: not installed or failed. Current temperature: 47 C (116 F). This module is on the rear of the shelf at the top left, on shelf module A.
```

```
[node-01: dsa_worker2: ses.status.temperatureWarning:alert]: DS224-12 (S/N SHFFG18330XXX4) shelf 0 on channel 0b temperature warning for Temperature sensor 11: not installed or failed. Current temperature: 47 C (116 F). This module is on the rear of the shelf at the top left, on shelf module A.
```

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information