



---

## 通过SSH登录到基板管理控制器(BMC)失败

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/SSH\\_login\\_to\\_Baseboard\\_Manageme...](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/SSH_login_to_Baseboard_Manageme...)

Updated: Wed, 22 Apr 2026 08:48:45 GMT

### 适用场景

- FAS2820
- 基板管理控制器(BMC) 17.3

### 问题描述

通过SSH登录到基板管理控制器(BMC)失败、无响应。