



## 系统生成"NVDIMMfailEndOfLifeAlert" DIMM-11故障

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/System\\_generates\\_NVDIMMFailEndOf...](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/System_generates_NVDIMMFailEndOf...)

Updated: Wed, 22 Apr 2026 09:01:28 GMT

### 适用场景

- ONTAP 9
- AFF A800、AFF C800、ASA A800、ASA C800
- AFF A400、AFF C400、ASA A400、ASA C400
- FAS8300、FAS8700

### 问题描述

在事件日志中、NVDIMM会显示以下警报：

```
[Node-01: env_mgr: nvdimm.nvmem.initfail:EMERGENCY]: NVMEM subsystem initialization failed because NVDIMM device in slot-11 has worn-out flash (0 percent remaining). To prevent NVMEM data loss, halt the system.
```

```
[Node-01: mgwd: callhome.hm.alert.critical:alert]: Call home for Health Monitor process nphm: NVDIMMfailEndOfLifeAlert [/dev/nvdimm0:Node-01].
```

