



# CXone Mpower EXPERT

## 系统在 "正在初始化系统内存 ..." 时挂起

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/System\\_hangs\\_at\\_Initializing\\_System\\_...](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/System_hangs_at_Initializing_System_...)

Updated: Wed, 22 Apr 2026 04:09:21 GMT

### 适用场景

- ONTAP 9
- AFF 和 FAS

### 问题描述

系统在 "Initializing System Memory ..." 处挂起、无法启动。

示例：

```
CPU = 1 Processor(s) Detected.  
Intel(R) Xeon(R) CPU D-1587 @ 1.70GHz (CPU 0)  
CPUID: 0x00050664. Cores per Processor = 16  
131072 MB System RAM Installed.  
SATA (AHCI) Device: SV9MST6D120GLM41NP
```

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

Boot Loader version 6.0  
Copyright (C) 2000–2003 Broadcom Corporation.  
Portions Copyright (C) 2002–2016 NetApp, Inc. All Rights Reserved.

BIOS Version: 11.7  
Portions Copyright (C) 2014–2018 NetApp, Inc. All Rights Reserved.

Initializing System Memory ...  
BIOS Version: 11.7  
Portions Copyright (C) 2014–2018 NetApp, Inc. All Rights Reserved.

Initializing System Memory ...  
BIOS Version: 11.7  
Portions Copyright (C) 2014–2018 NetApp, Inc. All Rights Reserved.

Initializing System Memory ...  
BIOS Version: 11.7  
Portions Copyright (C) 2014–2018 NetApp, Inc. All Rights Reserved.

Initializing System Memory ...