



# CXone Mpower EXPERT

对于PSU、所消耗的功率值显示为0

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/The\\_power\\_drawn\\_values\\_displayed\\_...](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/The_power_drawn_values_displayed_...)

Updated: Wed, 22 Apr 2026 07:32:39 GMT

## 适用场景

- ONTAP 9
- FAS2750

## 问题描述

该 `storage shelf show` 命令在“绘制的功率”列中显示的瓦特值不正确

```
cluster::> storage shelf show -power Shelf Name: 1.0 Stack ID: 1 Shelf ID: 0 Shelf UID:
XX:XX:XX:XX:XX:XX:XX:XX Serial Number: XXXXXXXXXXXXXXXX Module Type: IOM12E
Model: DS224-12 Shelf Vendor: NETAPP Disk Count: 24 Connection Type: SAS Shelf
State: Online Status: Normal Power Supply Units: Crest Power Reset PSU Operational ID
Type Part# Serial# Power Rating Factor Drawn Capable Enabled Firmware Status --- ----
----- 1 98 114-00148
A2 XXXXXXXXXXXXXXXX 913 0 0 false true 0110 normal 2 98 114-00148 A2
```

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

| XXXXXXXXXXXXXXXXXXXX 913 89 **1375** false true 0110 normal