



---

## 无法ping e0M端口

[https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/Unable\\_to\\_ping\\_e0M\\_port](https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/Unable_to_ping_e0M_port)

Updated: Wed, 22 Apr 2026 11:38:03 GMT

### 适用场景

- ONTAP 9
- 管理端口

### 问题描述

从客户端Ping 端口e0M失败