



NVRAM发生故障时会发生什么情况

https://kb-cn-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/What_will_happen_when_NVRAM_fails

Updated: Wed, 22 Apr 2026 08:49:05 GMT

适用场景

- 采用NVRAM的任何硬件平台
- ONTAP 9

问题解答

- NVRAM出现故障的节点将发生发生原因系统崩溃。
- 如果节点之间的HA互连在崩溃前失去同步、则会禁用接管。

追加信息

其他信息文本

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information