



关键驱动器损耗级别

https://kb-cn-stage.netapp.com/on-prem/SolidFire/Element_OS_Kbs/Critical_drive_wear_levels

Updated: Wed, 22 Apr 2026 09:37:39 GMT

适用场景

NetApp Element 软件

问题描述

集群警报和 NetApp SolidFire Active IQ 中会显示警报：

- Error Code `driveWearFault`
- 详细信息 `Drive with serial: <Drive serial number> in slot: X has critical wear levels`

出现上述警报后，还会显示其他警报：

- 错误代码：
 - `unresponsiveService`
 - `blockServiceUnhealthy`

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

- 详细信息:
 - A block service is not responding.
 - A block service is unhealthy and SolidFire is attempting to migrate data away from it.