



---

## Element 软件警报 CpuTherMalEventThreshold — AutoSupport 消息

[https://kb-cn-stage.netapp.com/on-prem/SolidFire/Element\\_OS\\_Kbs/Element\\_Software\\_Alert\\_CpuTher...](https://kb-cn-stage.netapp.com/on-prem/SolidFire/Element_OS_Kbs/Element_Software_Alert_CpuTher...)

Updated: Wed, 22 Apr 2026 06:53:25 GMT

### 适用场景

Element 软件 12.5 及更高版本。

### 事件摘要

CPU 散热事件数量已超过预定义的阈值，并且可以进行 CPU 限制

### 验证

确认 Element UI 警报选项卡或 Active IQ 错误日志中的警报尚未解决。

### 解决方法

此情况最可能与节点 BMC 无响应有关。

要解决此警报，报告这些事件的节点需要 [重新启动](#) 此节点，以解决底层 BMC 锁定问题描述。

---

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

Please contact [NetApp Technical Support](#) or log into the NetApp Support Site to [create a technical case](#). Reference this article for further assistance.

### 追加信息

在此处添加您的文本。