



NiCE

Element如何在集群节点之间分布卷

https://kb-cn-stage.netapp.com/on-prem/SolidFire/Element_OS_Kbs/How_does_Element_distributes_v...

Updated: Wed, 03 Jun 2026 19:17:16 GMT

适用场景

Element 软件

问题解答

- QoS最小IOPS是Element用于在集群中平衡卷/分区的值。
- 集群中的每个节点都会进行平衡、以使总最小IOPS数量大致相同。

追加信息

•SolidFire 根据过去2周的性能数据、根据近期活动的卷统计信息数据提供建议。建议侧重于卷的QoS最大和最小保证IOPS、只有在可能需要改进集群时、这些建议才会显示在UI中

Active IQ -> QoS管理->建议

- 要查看集群中节点的百分比限制、

Active IQ -> QoS管理->节点节管

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

- 有关QoS的信息

[NetApp SolidFire 服务质量\(QoS\)](#)