



---

## SolidFire 集群上无法访问的 VVol

[https://kb-cn-stage.netapp.com/on-prem/SolidFire/hardware\\_Kbs/Inaccessible\\_vVOLs\\_on\\_SolidFire\\_c...](https://kb-cn-stage.netapp.com/on-prem/SolidFire/hardware_Kbs/Inaccessible_vVOLs_on_SolidFire_c...)

Updated: Wed, 22 Apr 2026 10:05:01 GMT

### 适用于

- NetApp Element 软件 11.8
- NetApp SF-series
- NetApp H 系列

### 问题

无法访问 VVOL 数据存储库