



---

## NetApp HCI计算节点不会自动启动到ESXi

[https://kb-cn-stage.netapp.com/on-prem/SolidFire/hardware\\_Kbs/NetApp\\_HCI\\_compute\\_node\\_does\\_n...](https://kb-cn-stage.netapp.com/on-prem/SolidFire/hardware_Kbs/NetApp_HCI_compute_node_does_n...)

Updated: Wed, 22 Apr 2026 04:07:45 GMT

### 适用场景

NetApp HCI 计算节点

### 问题描述

- 计算节点无法启动
- 错误:

```
Port <#>: INTEL SSDSCKJB240G7
```

```
S.M.A.R.T Status Bad, Backup and Replace
```

```
Press F1 to Resume...
```

Version 2.19.1268. Copyright (C) 2018 American Megatrends, Inc.

NetApp M10025020 BIOS Date:07/13/2018 Rev:NA2.2

CPU : Intel(R) Xeon(R) Gold 5120 CPU @ 2.20GHz  
Speed : 2.20 GHz  
The DIMM is operating with DDR4 2400 MHz  
Entering Setup...

I-SATA1 : INTEL\_S5050A\_7B240G7  
S.M.A.R.T Status Bad, Backup and Replace.  
Press F1 to Resume...

Press DEL to run Setup  
Press F11 to invoke Boot Menu  
Press F12 to boot from PUE/LAN