



SolidFire 节点上的 NVRAM 设备警告 = {EnterpriseFlashControllertemperature:X C}

https://kb-cn-stage.netapp.com/on-prem/SolidFire/hardware_Kbs/NVRAM_device_warning_enterpriseF...

Updated: Wed, 22 Apr 2026 07:28:56 GMT

状态信息

适用于

- NetApp SolidFire SF 系列

问题

在 ActiveIQ 上：NVRAM device warning={enterpriseFlashControllerTemperature: 91 C}