



无法在SolidFire 卷上使用VMware转换器启用同步

https://kb-cn-stage.netapp.com/on-prem/SolidFire/hardware_Kbs/Synchronization_cannot_be_enabled...

Updated: Wed, 22 Apr 2026 07:30:30 GMT

适用场景

- VMware vCenter Converter独立6.3
- Element OS 12.3.1.103

问题描述

使用vCenter Converter将虚拟机转换为新的vSphere集群时、出现错误、指出"`Synchronization cannot be enabled if one or more volumes requires file-level cloning. Disable synchronization or refrain from resizing the destination volumes...`"