



EMS 事件"maxCID.threshold"或maxCID.Limit.exceeded.EMS 事件

https://kb-cn-stage.netapp.com/on-prem/ontap/da/NAS/NAS-KBs/EMS_Event_maxCID.threshold.exceed...

Updated: Wed, 22 Apr 2026 07:27:56 GMT

适用场景

- ONTAP 9
- EMS
- 最大CID

问题描述

[如果这会影响您的系统、请检查Active IQ](#)

此时将显示以下EMS消息：

`maxCID.threshold.exceeded` or `maxCID.limit.exceeded`

- 如果集群中的指示节点即将达到其可支持的最大主动/开放网络连接数、则会发生事件 `maxCID.threshold.exceeded` 。在这种情况下、客户端和/或应用程序可能会遇到服务中断

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

- 如果集群中的指示节点已超过其可支持的最大主动/开放网络连接数、则会发生事件`maxCID.limit.exceeded`。在这种情况下、客户端和/或应用程序最有可能发生服务中断