



NFS挂载正在使用IPsec断开连接

https://kb-cn-stage.netapp.com/on-prem/ontap/da/NAS/NAS-KBs/NFS_mounts_are_disconnecting_usi...

Updated: Wed, 22 Apr 2026 07:32:37 GMT

适用场景

- ONTAP 9.x
- IPsec

问题描述

使用IPsec断开连接定期挂载多个NFS