



NIS域绑定状态显示"域无效"

https://kb-cn-stage.netapp.com/on-prem/ontap/da/NAS/NAS-KBs/The_NIS_domain_bound_status_sho...

Updated: Wed, 22 Apr 2026 07:33:31 GMT

适用场景

- ONTAP 9
- NFS
- NIS

问题描述

命令"`nis-domain show-bound-debug`"显示 Bound Status 为"`Invalid Domain`"。

示例：

```
::*> vserver services name-service nis-domain show-bound-debug
```

Vserver	Domain	Bound NIS Server	Bound Status
---------	--------	------------------	--------------

svml	mynis.com	xx.xx.xx.39	Success
svm2	mynis.com	xx.xxx.xxx.37	Invalid Domain

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

