



---

## 删除LIF错误—命令失败：操作无效

[https://kb-cn-stage.netapp.com/on-prem/ontap/Ontap\\_OS/OS-KBs/delete\\_LIF\\_error\\_command\\_failed\\_...](https://kb-cn-stage.netapp.com/on-prem/ontap/Ontap_OS/OS-KBs/delete_LIF_error_command_failed_...)

Updated: Wed, 22 Apr 2026 09:27:22 GMT

### 适用场景

ONTAP 9

### 问题描述

- 尝试取消加入集群节点失败并显示错误。

```
clus01::*> cluster unjoin -node a200n1
```

```
Warning: This command will remove node "a200n1" from the cluster. You must  
remove the failover partner as well. After the node is successfully removed,  
erase its configuration and initialize all disks by using the "Clean  
configuration and initialize all disks (4)" option from the boot menu.
```

```
Do you want to continue? {y|n}: y
```

```
[Job 49617] Job is queued: Cluster remove-node of Node:a200n1 with
```

---

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

UUID:ef8597c5-17de-11e8-9a12-00a098b84809.

Error: command failed: [Job 49617] Job failed:

Failed to delete failover-group "fg\_vlan\_90" because it is still in use by the following LIFs: <vserver: svm\_servers, LIF: svm\_servers\_admin\_lif1>. Reassign these LIFs to use a new failover-group, then retry the cluster unjoin operation.

- 用于修改LIF故障转移组的命令失败并显示错误 invalid operation。

```
clus01::> net int modify -vserver svm_servers -lif svm_servers_admin_lif1
-failover-group fg_vlan_600
(network interface modify)
```

Error: command failed: invalid operation