



FlexGroup成员卷的大小显示过度配置

https://kb-cn-stage.netapp.com/on-prem/ontap/Ontap_OS/OS-KBs/FlexGroup_member_volume_shows...

Updated: Wed, 22 Apr 2026 07:32:28 GMT

适用场景

- ONTAP 9
- FlexGroup

问题描述

- FlexGroup `space-guarantee` 设置为 `none`
- FlexGroup成员卷的大小显示过度配置

示例：

```
cluster2::*> vol show -vserver svml_n1 -volume fg* -fields
size,available,used,size-used-by-snapshots,over-provisioned,space-
guarantee,aggregate
vserver volume aggregate size  available used  space-guarantee size-used-by-
snapshots over-provisioned
-----
```

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

```

-----
svml_n1 fg      -      300GB 261.9GB  4.81GB none      0B      23.33GB
svml_n1 fg__0001 aggr1_n1 33.33GB 31.44GB 234.4MB none      0B      0B
svml_n1 fg__0002 aggr2_n1 33.33GB 31.39GB 283.8MB none      0B      0B
svml_n1 fg__0003 aggr1_n2 33.33GB 31.44GB 232.4MB none      0B      0B
svml_n1 fg__0004 aggr1_n1 33.33GB 31.48GB 186.8MB none      0B      0B
svml_n1 fg__0005 aggr2_n1 33.33GB 30.46GB 1.21GB none      0B      0B
svml_n1 fg__0006 aggr1_n2 33.33GB 31.28GB 394.8MB none      0B      0B
svml_n1 fg__0007 aggr1_n1 133.3GB 76.00GB 260.6MB none
0B      57.08GB
svml_n1 fg__0008 aggr2_n1 33.33GB 31.46GB 207.5MB none      0B      0B
svml_n1 fg__0009 aggr1_n2 33.33GB 29.82GB 1.85GB none      0B      0B
10 entries were displayed.

```