



FlexGroup 重新平衡不会移动文件

https://kb-cn-stage.netapp.com/on-prem/ontap/Ontap_OS/OS-KBs/FlexGroup_rebalancing_doesn_t_m...

Updated: Wed, 22 Apr 2026 03:38:37 GMT

适用于

- ONTAP 9.12.1
- FlexGroup 重新平衡

问题描述

- 卷重新平衡开始但未取得进展：

```
::*> volume rebalance show -vserver svm1
Vserver: svm1
Target      Imbalance
Volume      State      Total      Used  Snapshots Used      Size      %
-----
svm1        rebalancing  300TB     41.09TB  1.86TB     -        18.85TB   45%
svm1____0001 scanning  60TB      27.07TB  741.4GB    8.22TB   18.85TB
229%
svm1____0002 idle    60TB      3.58TB   281.6GB    8.22TB   -4.64TB
```

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

```

-56%
svm1____0003 idle          60TB    3.07TB  187.8GB    8.22TB    -5.14TB
-62%
svm1____0004 idle          60TB    4.19TB  361.0GB    8.22TB    -4.03TB
-49%
svm1____0005 idle          60TB    3.18TB  334.4GB    8.22TB    -5.04TB
-61%

```

- 从 ASUP 中的 VOLUME-REBALANCE.XML 中，我们看到很多小文件被跳过
- 同样可以使用 `volume rebalance show` 和 `volume rebalance show -instance -volume <svm1____0001>`