



如何将备用驱动器归零以进行重建

https://kb-cn-stage.netapp.com/on-prem/ontap/Ontap_OS/OS-KBs/How_to_zero_spare_drives_for_rec...

Updated: Wed, 22 Apr 2026 08:48:10 GMT

执行

执行

适用场景

- ONTAP 9
- 集群模式 Data ONTAP 8.3
- 集群模式 Data ONTAP 8.2
- Data ONTAP 8.2 7-模式

问题描述

错误消息：`/vol0/plex0/rg0/0a.45 (S/N XXXXX): disk failure detected`

Data ONTAP 的早期版本可能会显示类似以下内容的消息：

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

错误消息：ERROR: unable to start reconstruction for /vol0/plex0/rg0: No zeroed disk of correct size available

(有关更多信息、请参见错误 [85383](#))

No zeroed disk of correct size available 尽管有相同大小的备用磁盘，但驱动器出现故障后仍会显示该消息。

出现磁盘故障信息。