



CXone Mpower EXPERT

Node Out of Quorum—AutoSupport消息

https://kb-cn-stage.netapp.com/on-prem/ontap/Ontap_OS/OS-KBs/Node_Out_Of_Quorum_-_AutoSup...

Updated: Wed, 22 Apr 2026 03:54:02 GMT

适用场景

- Node Out of Quorum—AutoSupport消息
- ONTAP 9

问题描述摘要

- 连接、活动性、可用性监控器(Cluster Monitor、简称"管理")是集群中每个节点用于监控其他节点可用性的功能。
- 如果在集群网络上检测到通信故障或节点中断、则会对隔离的节点启动HA接管、以维护故障节点数据的服务。
- 集群中的每个节点都将生成并发送一个AutoSupport、其中包含确定故障发生原因所需的诊断数据、并注明原因
NODE(S) OUT OF CLUSTER QUORUM。

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information