



ONTAP节点停用引用负载共享镜像卷失败

https://kb-cn-stage.netapp.com/on-prem/ontap/Ontap_OS/OS-KBs/ONTAP_node_decommissioning_fa...

Updated: Wed, 22 Apr 2026 07:31:27 GMT

适用场景

- ONTAP 9
- 负载共享镜像卷(LS镜像、LSM)
- 节点停用(`cluster remove-node` 命令)

问题描述

- `cluster remove-node` 命令失败、并显示类似以下内容的消息：

```
Error: [Job 65661] Job failed: Node "Cluster01-03" has 2 volumes. Please either move or delete them from the node before removing the node. The volumes are: <svml, svmlroot_m2>, <svm2, svm2root_m2>
```

- 引用的卷为SnapMirror目标、并且为只读卷
- `snapmirror break` 命令失败、并显示以下内容：

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

Error: snapmirror break is not allowed for destination Cluster01://svm1/svmlroot_m2 in a load-sharing relationship.