



mroot-state 恢复后根卷无法正常工作

https://kb-cn-stage.netapp.com/on-prem/ontap/Ontap_OS/OS-KBs/Root_volume_not_working_properly...

Updated: Wed, 22 Apr 2026 07:28:55 GMT

适用场景

- ONTAP 9
- 双节点MetroCluster

问题描述

根卷需要恢复

```
***** ** SYSTEM MESSAGES ** ***** Internal error: Cannot open corrupt replicated database. Automatic recovery attempt has failed or is disabled. Check the event logs for details. This node is not fully operational. Contact support personnel for the root volume recovery procedures.
```

```
LOADER-A> printenv bootarg.rdb_corrupt
```

Variable Name	Value
---------------	-------

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

```
bootarg.rdb_corrupt <any value>
```