



---

## 无法访问SPI

[https://kb-cn-stage.netapp.com/on-prem/ontap/Ontap\\_OS/OS-KBs/Unable\\_to\\_access\\_SPI](https://kb-cn-stage.netapp.com/on-prem/ontap/Ontap_OS/OS-KBs/Unable_to_access_SPI)

Updated: Wed, 22 Apr 2026 07:03:41 GMT

### 适用场景

- ONTAP 9
- Cloud Volume ONTAP (CVO)

### 问题描述

- 尝试访问SPI和System Manager时出现以下错误。



## This site can't be reached

10 .XX.XX.133 refused to connect.

Try:

- Checking the connection
- [Checking the proxy and the firewall](#)

ERR\_CONNECTION\_REFUSED

Reload

Details

- 这是一个新设置。
- 按照以下知识库文章中的说明启用对集群中节点根卷的远程访问。  
[如何启用对集群中节点根卷的远程访问](#)