



CXone Mpower EXPERT

“忽略不一致设置”为“开”意味着什么？

https://kb-cn-stage.netapp.com/on-prem/ontap/Ontap_OS/OS-KBs/What_does_ignore_inconsistent_se...

Updated: Wed, 22 Apr 2026 08:25:42 GMT

不
可不使用

适用于

- Data ONTAP 7 及更早版本
- Data ONTAP 8
- ONTAP 9

解答

- 如果将此值设置为 **on** 、 Data ONTAP 将忽略存在或可能出现的任何文件系统不一致性。
- 如果设置为 **On** （开），请联系 NetApp 技术支持以解决此问题。
- [如果这会影响您的系统，请检查 Active IQ](#)

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

- 要通过 CLI 进行检查，请运行以下命令：

```
::>storage aggregate show -aggregate <aggr>
```

- 示例：

```
filer::> storage aggregate show -aggregate aggr0
```

```
Aggregate: aggr0
Checksum Style: block
Number Of Disks: 3
Mirror: false
Node: filer
Disks for First Plex: 1.21.0, 1.21.1, 1.21.3
Disks for Mirrored Plex: -
Partitions for First Plex: -
partitions for Mirrored Plex: -
Free Space Reallocation: off
HA Policy: cfo
Ignore Inconsistent: on
Space Reserved for Snapshot Copies: 5%
Aggregate Nearly Full Threshold Percent: 97%
Aggregate Full Threshold Percent: 98%
Block Checksum Protection: on
```

其他信息

对于以 7 模式运行的 Data ONTAP，请运行 `aggr status` 命令检查状态。