



何时触发SPNotConfiguredAlert？

https://kb-cn-stage.netapp.com/on-prem/ontap/Ontap_OS/OS-KBs/When_will_the_SPNotConfiguredAl...

Updated: Wed, 22 Apr 2026 07:17:07 GMT

适用场景

ONTAP 9

问题解答

如果在集群中禁用了自动服务处理器(SP)或底板管理控制器(BMC)固件更新、则系统将在节点重新启动或ONTAP更新时发出SPNotConfig要么已配置的运行状况监控器警报。

追加信息

- [运行状况监控器警报SPNotConfiguredAlert](#)
- [如何禁止SPNotConfiguredAlert](#)
- [禁用SP或BMC自动更新后、SPNotConfigured警报会定期出现](#)

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information