



## 如何更改文件管理器节点上的各个固件映像

[https://kb-cn-stage.netapp.com/on-prem/ontap/Upgrade/Upgrade-KBs/How\\_to\\_change\\_individual\\_firm...](https://kb-cn-stage.netapp.com/on-prem/ontap/Upgrade/Upgrade-KBs/How_to_change_individual_firm...)

Updated: Wed, 22 Apr 2026 07:31:06 GMT

### 适用场景

ONTAP 9

### 问题描述

手动降级后、不需要的较新ONTAP版本的固件映像仍显示在系统节点映像中、如下所示：

```
cluster99::*> system node image show
```

Node	Image	Is Default	Is Current	Version	Install Date
node1	image1	false	false	9.14.1P1	10/10/2024 07:05:20
	image2	true	true	9.11.1P10	12/17/2024 04:13:12
node2	image1	false	false	9.14.1P1	10/10/2024 07:05:22
	image2	true	true	9.11.1P10	12/17/2024 04:18:24

4 entries were displayed.

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information