



如果LIF已关闭、则ONTAP升级失败

https://kb-cn-stage.netapp.com/on-prem/ontap/Upgrade/Upgrade-KBs/ONTAP__upgrade_fails_when_t...

Updated: Wed, 22 Apr 2026 08:24:22 GMT

适用于

ONTAP 9.10.1及 更高版本

问题

ONTAP升级失败、并显示以下错误：

```
Cluster::> cluster image show-update-progress
```

Update Phase	Status	Estimated Duration	Elapsed Duration
Pre-update checks	completed	00:10:00	00:01:06
ONTAP updates	paused-on-error	01:32:00	00:09:07

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

Details:

Node name	Status	Status Description
Node1	waiting	
Node2	failed	Error: Failed to migrate data LIFs from node "Node2". Action: Migrate all of the data LIFs using the "network interface migrate-all -node Node2" command.