



CXone Mpower EXPERT

ifgrp端口已转换为非活动状态

https://kb-cn-stage.netapp.com/on-prem/Switches/Cisco-KBs/An_ifgrp_port_has_transitioned_to_an_in...

Updated: Wed, 22 Apr 2026 10:27:39 GMT

适用场景

- FAS 2750
- Cisco Nexus 交换机

问题描述

- ifgrp端口会过渡到非活动状态、从而导致接口组进入降级状态。
- EMS.log 产出

```
[node-01: mgmt_port_link_status_poll:netif.linkDown:debug]: Ethernet e0f: Link down, check cable.
```

```
[node-01: mgmt_port_link_status_poll:netif.linkDown:debug]: Ethernet a0a: Link down, check cable.
```

```
[node-01: intr:net.ifgrp.lacp.link.inactive:debug]: ifgrp a0a, port e0f has transitioned to an inactive state. The interface group is in a degraded state.
```

```
[node-01: mgmt_port_link_status_poll: netif.linkDown:debug]: Ethernet a0a-202:Link
```

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

down, check cable.

[node-01: mgmt_port_link_status_poll: netif.linkDown:debug]: Ethernet a0a-2224:Link down, check cable.

[node-01: mgmt_port_link_status_poll: netif.linkDown:debug]: Ethernet a0a-222:Link down, check cable.

[node-01: mgmt_port_link_status_poll: netif.linkDown:debug]: Ethernet a0a-201:Link down, check cable.

[node-01: vifmgr: vifmgr.lifmoved.linkdown:debug]: LIF lif_name (on virtual server xxxxxxxx), IP address xx.xx.xxx.xx, is being moved to node node-01, port a0a-201.