



Brocade 导向器开关传感器显示高温传感器

https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/Brocade_director_switch_sensor_sho...

Updated: Wed, 22 Apr 2026 08:25:11 GMT

适用场景

Brocade 交换机 X6

问题描述

- Brocade 导向器开关传感器显示温度过高。

示例：

```
/fabos/cliexec/sensorshow:  
sensor 1: (Temperature) is Ok, value is 25 C  
.  
.  
sensor 19: (Temperature) is Absent  
sensor 20: (Temperature) is Ok, value is 69 C  
sensor 23: (Fan      ) is Ok, speed is 4029 RPM  
sensor 24: (Fan      ) is Ok, speed is 3814 RPM  
sensor 25: (Power Supply) is Ok  
sensor 26: (Power Supply) is Ok
```

- 风扇转速似乎正常

示例：

```
/fabos/cliexec/fanshow:  
Fan 1 is Ok, speed is 4032 RPM  
Fan 2 is Ok, speed is 4000 RPM
```

- 日志中未显示任何警告迹象或故障。