



## Brocade 风扇转速下降、转速恢复正常

[https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/Brocade\\_FAN\\_dropping\\_RPM\\_spinnin...](https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/Brocade_FAN_dropping_RPM_spinnin...)

Updated: Wed, 22 Apr 2026 09:01:34 GMT

### 适用场景

Brocade FOS v8.2.2和以下版本

### 问题描述

风扇降至RPM阈值以下、然后再次旋转至正常状态

#### 错误:

```
CHASSIS, ERROR, BrocadeG620, Fan 2 sensor 1 , speed (2649 RPM) below threshold.  
CHASSIS, ERROR, BrocadeG620, Fan 2 set to faulty, rc=20006.  
CHASSIS, INFO, BrocadeG620, Fan 2 is no longer faulted.  
CHASSIS, ERROR, BrocadeG620, Fan 2 sensor 1 , speed (2649 RPM) below threshold.  
CHASSIS, ERROR, BrocadeG620, Fan 2 set to faulty, rc=20006.  
CHASSIS, INFO, BrocadeG620, Fan 2 is no longer faulted.
```

```
CHASSISCMD /fabos/cliexec/fanshow:
```

```
*****
```

```
/fabos/cliexec/fanshow:
```

```
Fan 1 is Ok, speed is 8043 RPM
```

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

Fan 2 is Ok, speed is 8341 RPM

errshow -r

Fabric OS: v8.2.2

[EM-1037], 1506, CHASSIS, INFO, BrocadeG620, Fan 2 is no longer faulted.

Type to continue, Q to stop:

[HIL-1301], 1505, CHASSIS, WARNING, BrocadeG620, 1 blower failed or missing. Replace failed or missing blower assembly immediately.

Type to continue, Q to stop:

[EM-1034], 1504, CHASSIS, ERROR, BrocadeG620, Fan 2 set to faulty, rc=20006.

Type to continue, Q to stop:

[HIL-1206], 1503, CHASSIS, ERROR, BrocadeG620, Fan 2 sensor 1 , speed (2649 RPM) below threshold.

Type to continue, Q to stop:

[EM-1037], 1502, CHASSIS, INFO, BrocadeG620, Fan 2 is no longer faulted.