



---

## Brocade 交换机无法使用致命 CF 卡启动 失败

[https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/Brocade\\_switch\\_unable\\_to\\_boot\\_with...](https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/Brocade_switch_unable_to_boot_with...)

Updated: Wed, 22 Apr 2026 10:27:28 GMT

### 适用场景

- Brocade 6505
- FC

### 问题描述

- 无法启动交换机。交换机控制台显示以下错误：

```
kernel: : hda: task_in_intr: error=0x44 { DriveStatusError UncorrectableError },  
LBAsect=1676819, sector=1675819
```

```
A fatal CF card failure has been detected. The system will be rebooted. Please  
contact your service provider for CF card replacement
```

- `printenv` 在命令 `shell/boot` 菜单中显示 `CFCardState=bad`

---

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

```
=> printenv  
AutoLoad=yes  
BootromVerbose=no  
CFCardState=bad
```