



Brocade交换机的端口出现C3错误

https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/Brocade_switch_with_c3_errors_on_port

Updated: Wed, 22 Apr 2026 08:48:05 GMT

适用场景

Brocade光纤交换机

问题描述

- `porterrshow` 的输出指示 `enc in`、`crc err`、`crc g_eof`、`bad eof`、`enc out`、`disc c3` 和 `c3 timeout TX` 错误计数器。

```
      frames   enc   crc   crc   too   too   bad   enc   disc   link   loss
loss  frjt   fbsy  c3timeout
      tx    rx    in   err   g_eof  shrt   long  eof    out   c3    fail   sync
sig          tx    rx
=====
7:    2.4m   6.3m  76.9k  42.5k  42.3k  0     0     208   1.0g  39    0     0
      0     0     0     20    0
```

- 仅在完成以下故障诊断步骤后继续使用解决方案。

'NetApp provides no representations or warranties regarding the accuracy or reliability or serviceability of any information or recommendations provided in this publication or with respect to any results that may be obtained by the use of the information or observance of any recommendations provided herein. The information in this document is distributed AS IS and the use of this information or the implementation of any recommendations or techniques herein is a customers responsibility and depends on the customers ability to evaluate and integrate them into the customers operational environment. This document and the information

- 重新拔插并清洁电缆两端、包括配线板。
- 重新拔插两端的SFP。