



---

## CP 设置为故障，因为 FOS 升级期间断言了 CP ERROR

[https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/CP\\_set\\_to\\_faulty\\_because\\_CP\\_ERR...](https://kb-cn-stage.netapp.com/on-prem/Switches/Brocade-KBs/CP_set_to_faulty_because_CP_ERR...)

Updated: Wed, 22 Apr 2026 08:25:11 GMT

### 适用场景

Brocade FOS

### 问题描述

FOS 升级期间出现的错误消息

■ CP in Slot 2 set to faulty because CP ERROR asserted.